

Tumbler should be set at $1rac{1}{4}$ " below machined grate seat

Once grate is set in frame, torque bolt $\frac{1}{4}$ turn past snug

SURFACES ON BOTH FRAME

NOTE: SEAT

AND GRATE ARE MACHINED AND GRATE MUST NOT ROCK IN FRAME WHEN ASSEMBLED.

WEIGHTS: 3-FLANGE FRAME 4-FLANGE FRAME B-1 GRATE

 $\Sigma \Sigma \Sigma$ 240 LBS N 270 LBS N 265 LBS N

NOTE: IDENTIFYING INFORMATION SHOWN ON FRAMES & GRATES TO BE CAST WITH FRAME AND GRATE

CASTING TOLERANCES:SHALL CONFORM TO AASHTO M306

SSUE DATE **JAN 2025**

DRAWING NUMBER 222.1.2